

Vivarium Electronics

I 10 Rack Assembly Instructions

Uses: I 80 and I 160 Tubs Available at: reptilebasics.com



Congratulations on your purchase.
 Locate and familiarize yourself with the parts:
 Side A Panel (1 each)
 Side B Panel (1 each)
 Inner Back Panel (1 each)
 Outer Back Panel with Heat Tape (1 each)
 Top Shelf (1 each)
 Bottom shelf (1 each)
 Center Shelves (9)
 Screw Kit (1) (Not Pictured)

Begin with the bottom shelf and side panel. Position the edge of the shelf in the first slot. Notice the orientation in the image. The "feet" on the side panel indicate the bottom of the panel. The alignment notches indicate the rear of the panel.

The rounded edge of the shelf with the protrusions on each side indicates the front of the shelf. The rounded edge indicates the top of the shelf.

Make sure the protrusions on the shelf front are in the front and flush against the front of the side panel. Using a screwdriver and the bit supplied, secure the shelf with screws through the 2 predrilled holes in the panel. Please note that the rear most screw holes in the panel are for attaching the outer back panel. Do not install this screw at this time. **Do Not Over Tighten Screws**
 Repeat this with The other side panel.

Once you have both sides attached to the bottom shelf, stand the assembly up and starting toward the bottom, install the shelves one at a time. To insure proper fit sure to use a tub at each end of the shelf as a spacer. Install shelves one at a time securing the one screw toward the front (another screw in the center for the bottom shelf, one center shelf and top)





Once the shelves and top are secure you are ready to install the back panels. To do this place the assembly front down and locate the inner back panel. Place the inner back panel onto the back of the rack making sure to align the "feet" to the rack bottom and the alignment tabs in the slots provided. Next manipulate the shelf protrusions into the slots in the panel. Gentle manipulation with a screwdriver or other tool may be needed. Once in place secure the panel with screws using the pre drilled holes.



Once the inner back panel is secured place the outer back panel into place over the inner back panel. Make sure the power cord passes through the provided slot. Power cord is to the top of the rack. Once in place secure the panel with screws passing through the pre drilled holes in the side panel. The rack is ready!



Probe Placement: Locate the slot in the center of the back panel and insert probe. Slide the probe in until it is hidden. Use gray tape to secure probe and cover the opening.

